

SETTING THE REMOTE TO CONTROL YOUR TV

POWER AND VOLUME:

1. Turn your TV set on manually (walk up to your TV set and push the power button).
2. Press the white "TV" button at the top left of the remote. This puts the remote in "TV Only Mode."
3. Push and hold the "SETUP" button (found under the TV button) until the "TV" button blinks twice.
4. Let go of the "SETUP" button.
5. Key into the number pad "9 9 1"
6. Aim the remote at your TV set and push the "Channel +" button.
 - a. If the TV set turns off, push the "SETUP" button again and the "TV" button will blink twice.
 - b. If the TV set does not turn off, keep pushing the "Channel +" button until the TV does go off.
 - You cannot just hold the Channel + button in. You must continually press it and let go.
 - This may take up to 300 button presses depending on your TV manufacturer.
 - c. Once the TV turns off, press the "SETUP" button and the "TV" button will flash twice.

